

Critical root zone (CRZ) of a tree is a cylinder extending from grade level down to a depth of ten (10) feet below grade, having a radius in feet equal to the diameter at breast height (DBH) of the tree in inches, with the center of the cylinder located at the center of the trunk